

Operation of the 'power-on' switch will then illuminate the LED signal lamp. Power on the RHC is applied by the power button see *Figure 1*.

*Figure 1*



**NOTE:** When in Control Mode boxes inside of indicators will be **GREEN**. When in Go To Ground Mode boxes inside of indicators will be **BLUE**.